

visible at edge of metal

washer. Assembly is

weather tight.

visible, not enough

compression to seal

properly.

Neoprene washer

extruded beyond edge

of washer.

FASTENER PLACEMENT

Low sloped roofs and high wind areas.

